

ENG / SLO / CRO



ENVY

Box Contents

1. UVI Gear Envy RGB Gaming Mouse
2. User Manual

System Requirements

1. Operating System:
Windows XP/7/8/10 or MAC OS
2. One free USB 2.0 or 3.0 port

 User Manual

 Navodila za uporabo

 Korisnički priručnik

Choose your language

UVI Gear Envy is a plug and play RGB Gaming Mouse that supports on-board memory and offers additional enhanced settings via downloadable software. To further enhance your experience make sure to use software that can be downloaded at www.uvigear.com/dl. At the start choose the language of the software as shown in the picture below.

Izberi svoj jezik

UVI Gear Envy je "plug and play" RGB igralna miška, ki ima vgrajen pomnilnik in preko programske opreme ponuja dodatne možnosti nastavitve. Da bi še dodatno izboljšali svojo izkušnjo, ne pozabite prenesti dodatne programske opreme na www.uvigear.com/dl.

Na začetku izberite jezik programske opreme, kot je to prikazano na spodnji sliki.

Odaberite svoj jezik

UVI Gear Envy je "plug and play" RGB gaming miš, koji ima ugrađenu memoriju i nudi dodatne postavke putem softvera, koji pruža dodatne mogućnosti podešavanja. Da biste dodatno poboljšali svoje iskustvo, ne zaboravite preuzeti dodatni softver na www.uvigear.com/dl.

Prvo odaberite jezik softvera, kao što je prikazano na slici ispod.



Software

Lighting

You can customize RGB lighting by clicking on "Lighting" button. There you can choose desired color, brightness and effect. If you would like to use a single color lighting select static mode.

Osvetlitev

RGB osvetlitev lahko prilagodite s klikom na gumb "Osvetlitev". Tam lahko izberete željeno barvo, svetlost in učinek. Če želite uporabiti enobarvno osvetlitev, izberite statični način.

Rasvjeta

RGB rasvjeto možete prilagoditi klikom na gumb "Rasvjeta". Tamo možete izabrati željenu boju, svjetlinu i efekt. Za upotrebu jednobojne rasvjete odaberite statički način.





🇬🇧 How to set-up and use Macros

To create a new macro click on "Macro" button on the left. Input desired name and press +. Then press RECORD and input desired combination of keys. Before you save, you can edit delay or time/cycle of the input keys. After that save your new macro.

To use the new macro click on "Customize" button. Select the key you want to use for your macro. After you choose the button select "Macro" and choose the macro combination you want to add. At the end press "APPLY" to save your preferences.

🇸🇮 Kako nastavit i uporabljati makra

Če želite ustvariti nov makro, kliknite gumb "Makro" na levi strani. Vnesite želeno ime in pritisnite +. Nato pritisnite SNEMAJ in vnesite želeno kombinacijo tipk. Pred shranjevanjem lahko uredite zamudo ali čas/cikel pritisnjenih tipk. Nato shranite svoj novi makro.

Če želite uporabiti nov makro, kliknite na gumb "Prilagodi". Izberite ključ, ki ga želite uporabiti za svoj makro. Ko izberete gumb, izberite "Makro" in izberite kombinacijo makrov, ki jih želite dodati. Za shranitev nastavitve na koncu pritisnite gumb "UPORABI".

🇮🇹 Kako postaviti i koristiti makronaredbe

Da biste stvorili novi makronaredbu, kliknite gumb "Makro" na lijevoj strani. Unesite željeno ime i pritisnite +. Zatim pritisnite SNIMANJE i unesite željenu kombinaciju tipki. Prije pohrane možete urediti odgodu ili vrijeme/ciklus tipki. Nakon toga spremite novu makronaredbu.

Za upotrebu novog makronaredbe kliknite gumb "Prilagodi". Odaberite ključ koji želite upotrijebiti za svoju makronaredbu. Nakon što odaberete gumb, odaberite "Makro" i odaberite kombinaciju makronaredbi koju želite dodati. Na kraju pritisnite "PRIHVATI", da biste spremili svoje postavke.

🇬🇧 DPI Settings

Customize your mouse DPI Levels, Sensitivity, Scrolling Speed and DPI Report Rate.


🇸🇮 DPI nastavitve

Prilagodite DPI stopnje miške, občutljivost, hitrost zaslonskega pomikanja in hitrost DPI poročanja.

🇮🇹 DPI postavke

Prilagodite DPI razine miša, osjetljivost, brzinu pomicanja i brzinu DPI izvještavanja.





	 ENG	 SLO	 HR
KEY	CUSTOMIZE	PRILAGODI	PRILAGODI
1	LEFT CLICK	LEVI KLIK	LJEVI KLIK
2	RIGHT CLICK	DESNI KLIK	DESNI KLIK
3	FORWARD	NAPREJ	NAPRIJED
4	MIDDLE CLICK	SREDINSKI KLIK	SREDIŠNJI KLIK
5	BACKWARD	NAZAJ	NATRAG
6	DPI +	DPI +	DPI +
7	DPI SHIFT	DPI ZAMIK	DPI ODGODA
8	DPI -	DPI -	DPI -

Warning / Opozorilo / Opomena



Do not attempt to open, service or modify the mouse.
Clean the mouse using only a dry cloth; do not use alcohol or detergent.
Keep away from water or fire and do not expose to high temperatures.



Miške ne poizkušajte odpirati, popravljati ali modificirati.
Miško čistite samo z uporabo suhe krpe; ne uporabljajte alkohola ali detergenta.
Držite stran od vode in odprtega ognja ter jo ne izpostavljajte visokim temperaturam.



Ne pokušavajte otvarati, popravljati ili mijenjati miš.
Očistite miša samo suhom krpom; ne koristite alkohol ili deterdžent.
Držite podalje od vode i otvorenog plamena i ne izlažite visokim temperaturama.